

# MONTAGEANLEITUNG

## Gleitringdichtung SDV-Balloon


werkseitig vorgeschmiert  
für Schächte nach  
DIN 4034-1 und  
FBS Qualitätsrichtlinie



**1. Dichtung**  
– Gleitmantel  
nach oben und  
außenzeigend –  
auf das saubere  
Spitzende auf-  
ziehen, Vorspan-  
nung durch mehr-  
faches Ziehen  
an verschie-  
denen Stel-  
len gleichmäßig  
verteilen und auf  
richtigen  
Sitz der  
Dichtung an der  
Schulter achten.



**2. TOPSEAL**  
Basic Last-  
ausgleichs-  
element  
lose auf den  
äußeren Rand  
des Spitzendes  
mittig auflegen.  
Schachtring zent-  
risch und gerade  
hängend aufset-  
zen und aufglei-  
ten lassen.



**Muffe und Dichtung nicht einfetten,  
Dichtung ist selbstschmierend!**

**3. Prüfen, ob der  
Schachtring richtig  
aufliegt. Evtl. leicht  
nachdrücken. Bei  
Wiedermontage  
darauf achten,  
dass sich der  
Gleitmantel wieder  
in der Ausgangs-  
position befindet.**



**DS**  
DICHUNGSTECHNIK

DS Dichtungstechnik GmbH  
Lise-Meitner-Straße 1  
48301 Nottuln, Germany  
Telefon: +49 (0)2502/2307-0  
Telefax: +49 (0)2502/23 07-30  
E-Mail: info@dsseals.com

[www.dsseals.com](http://www.dsseals.com)

# ASSEMBLY INSTRUCTIONS



## Sliding-ring seal SDV-Balloon

Pre-lubricated for  
Manholes according to  
DIN 4034-1 and  
FBS quality-guidelines




**1. Pull seal with mantle on top around on the cleaned spigot end, distribute tensioning evenly by repeated pulling at different spots.**

**SD-Victory seal should rest firmly against spigot shoulder.**



**2. Do not grease Belt or Seal, self-lubricating! Centre the manhole in the belt and hanging down straight and push manhole home. TOPSEAL Basic weight-balancing elements are a modern alternative for mortar**



**With TOP Seal Basis you reach a higher security and efficiency.**

**3. Test whether the manhole is fitting correctly. Make adjustments, if necessary. In case of re-assembly, check that the mantle is in its initial position.**



**DS**  
DICHUNGSTECHNIK

DS Dichtungstechnik GmbH  
Lise-Meitner-Straße 1  
48301 Nottuln, Germany  
Telefon: +49 (0)2502/2307-0  
Telefax: +49 (0)2502/23 07-30  
E-Mail: info@dsseals.com

[www.dsseals.com](http://www.dsseals.com)